

SMART CLASSROOMS SYSTEM GUIDE

Updated 9/1/2019



Table of Contents

Getting help during class.....	1
Lectern Equipment Description Layout.....	2
Equipment description..... (Touch panel & Smart Pen monitor)	3
Equipment description..... (Laptop connections)	4-5
Equipment description..... (Computer & Annotation tablet)	6
Equipment description..... (USB Ports, Power Point Clicker, Podium light & Microphone)	7
Classroom Accessories..... (Overhead dimmer lights & ITS phone)	8
Projector Startup/Shutdown.....	9-10
Connecting your Windows Laptop.....	11
Connecting your Apple Laptop	12
Troubleshooting your laptop connection.....	13
Connecting an Apple IOS handheld device (older generation).....	14
Connecting an Apple IOS handheld device (newer generation).....	15
Android connection guide.....	16
Using the Wacom Cintiq Pro 13" tablet.....	17-18
Power Point Presenter view.....	19
Document Camera & Microphone Smart Classroom locations.....	20

Getting Help During Class

Contact ITS Smart Support during teaching hours

Monday – Thursday, 8am – 11pm

Friday, 8am – 5pm


Saturday-Sunday, 9am – 5pm

**Call the Classroom IT Hotline:
718.951.HELP (x4357)**

The Classroom IT Hotline

718.951.HELP


Equipment Description & Layout



Equipment Description


Touch Panel, Symodium/Smart Pen monitor

TOUCH PANEL



By default, the touch panel may be dark. To power on, firmly press the screen to wake up. Refer to pages 11-12 for further instructions.

Symposium/Smart pen monitor




For a Symposium/Smart Pen monitor training please call us at x4357 to schedule a training.

NOTE: Smart Pen monitors are slowly being phased out. As a replacement, ITS has installed a Wacom Cintiq Pro 13" annotation tablet. See page 6 for a list of locations. See page 17-18 for instructions on how to use the tablet.

Equipment Description

Laptop Connections



- **Ethernet Cable** – Internet capabilities on your laptop.
- **Thunderbolt** – Apple laptops (2011 – today), older laptops will need an Apple mini-dvi to VGA adapter. Refer to page 11 for connection instructions.
- **HDMI** – Current laptop models - Refer to page 11 for connection instructions
- **VGA** – Refer to page 11 for connection instructions
- **Aux Audio cable** – Refer to page 11 for connection instructions
- **Power** – Used to power laptops, phones, etc

Podium Laptop Connections



HDMI



Apple laptop



VGA Video



VGA Audio



Internet

For assistance please call the [ITS Help Desk at ext.4357](tel:4357)

Equipment Description Computer & Annotation Tablet

Mac Mini



OR

Dell Windows Computer



DVD/VHS

NOTE: As of September 2018 ITS has begun phasing out the DVD/VHS units in our Smart Classrooms. In place of the DVD player, please see use the podium computer's DVD disc drive.

For VHS users, please contact the ITS Help Desk ext. 4357 for an alternative solution.

*The following rooms are equipped with
an Apple Mac Mini*

Ingersoll Hall: 0105, 2213, 2239
James Hall: 2305
Boylan Hall: 3129
Whitehead Hall: 421 & 508
Roosevelt Ext: 206RE

Wacom Cintiq Pro 13"



*The following rooms are equipped with
a Wacom Cintiq Pro 13" - Annotation
Tablet*

Ingersoll Hall: 1105N, 1127N, 1310N, 2310N,
2127N, 3127N, 3413N

New Ingersoll Hall: 148NE, 329NE

Boylan Hall: 3139

Whitehead: 320A

See Pages 17-18 for instructions on how to use the tablet to annotate. Call the ITS Help Desk at ext. 4357 for an updated list of newly installed tablets.

Equipment Description

USB Ports, Power Point Clicker, Podium light & Microphone

USB Faceplate



Two USB 3.0 ports are present to connect USB storage devices such as flash drives and external drives to a Smart Classroom's podium computer.

POWER POINT CLICKER



PowerPoint clickers can now be obtained at the Library ITS Help Desk. For more information please call us at ext 4357.

Podium Light



Microphone

See page 17 for microphone classroom locations. To schedule a training, call the ITS Help Desk at 4357




Classroom Accessories


Overhead Dimmer Lights & ITS Phone



Dimmable high hat lights are provided. The light switch can be found next to the ITS phone.



Use the ITS Help Desk hotline to call for support during any class including evenings and weekends to call for additional support.




Our support number can be found near the ITS phone and on each Smart Classroom podium.

Projector Startup/Shutdown


1 To begin, power on the system by touching "PRESS TO BEGIN".




2 Wait 60 seconds for the projector to power on.




3 Choose a video source to display onto the projection screen.




4 Computer Source




5 Laptop Source. See page 11-12 for additional laptop connection information.



6 Doc Cam – Not installed in every classroom, see page 17 for locations.




7 Microphone – Not installed in every classrooms, see page 17 for locations.



8 Use these controls To adjust the volume.



9 Use the Video Mute button to hide what is being displayed on the projection screen. Press again to display.




Projector Startup/Shutdown

(continued)


- 10** Use this button to shutdown the system. See Step 6 & 7 for further instructions



- 11** Press Yes to confirm projector shutdown or No to go back to the main page.



- 12** The projector will take 60 seconds to shutdown.



Windows Laptop Connection Guide




OR



Trouble connecting?
Refer to page 13 on the System
Guide book.

Apple Laptop Connection Guide



**Trouble connecting?
Refer to page 13 on the System
Guide book.**

Troubleshooting Your Laptop Connection

If the projector does not detect your **Windows Laptop** follow these instructions

- On your laptop: Press both the Windows Logo key and the P key
- Then click on Duplicate



If the projector does not detect your **Apple laptop** follow these instructions

- On your Apple laptop: Press both the Command and F1 key



Apple iOS Device Connection Guide

A 30 pin to VGA adapter will be needed to connect the following devices:

- iPad 2
- iPhone 4S
- iPod touch 4th Generation



The Apple VGA adapter supports mirroring of what is displayed on your device screen including apps, presentations, websites, slideshows and YouTube content.

***ITS has a limited supply of adapters on-hand for faculty use. Adapters can be purchased on-line at Amazon, Apple, Monoprice, or Radio Shack.**

Apple iOS Device Connection Guide

An Apple Lightning to HDMI adapter will be needed to connect the following devices:

- iPad with Retina Display
- iPad mini
- iPhone 5
- iPod 5th Generation



The Lightning to HDMI adapter supports mirroring of what is displayed on your device screen including apps, presentations, websites, slideshows and YouTube content.

***ITS has a limited supply of adapters on-hand for faculty use. Adapters can be purchased on-line at Amazon, Apple, Monoprice, or Radio Shack.**

Android Connection Guide

The MHL to HDMI adapter supports mirroring of what is displayed on your device screen including apps, presentations, websites, slideshows and YouTube content.




Compatible Mobile Devices		
Samsung	HTC	LG
Galaxy S III (GT-I9300)*	One XL	Optimus 4X HD
Verizon Galaxy Nexus LTE	One X	Optimus LTE II
Sprint Galaxy Nexus	One S	Optimus LTE Tag
Galaxy Nexus (I9250)	EVO 4G LTE	Optimus 3D Max
AT&T Galaxy Note LTE 5.3*	Raider	Optimus 4X HD
Galaxy Note 5.3*	Velocity	Optimus Vu
Sprint Epic 4G Touch	Vivid	Verizon Spectrum
AT&T Galaxy S II Skyrocket (I727)	Rezound	Prada
T-Mobile Galaxy S II (T989)	Amaze 4G	Nitro HD
AT&T Galaxy S II (I777)	Sensation XE	
Galaxy S II (I9100)	JetStream	
Infuse	Sensation 4G	
Galaxy S4*	EVO View 4G	
	EVO 3D	
	Sensation	
	Flyer	

* The Samsung Galaxy S III and S4 requires the use of an [11-to-5 pin Micro USB adapter](#) to use a standard 5-pin MHL adapter.

***ITS has a limited supply of adapters on-hand for faculty use. Adapters can be purchased on-line at Amazon, Apple, Monoprice, or Radio Shack.**

Using the Wacom Cintiq Pro 13" tablet

- 1 Lift the tablet's case up to open.



- 2 If the tablet is turned off, press the power button located on top of unit.



- 3 If the tablet is powered on but not receiving a video signal, then ensure the video cable has been re-seated. Ensure that the computer is turned on as well.




Using the Wacom Cintiq Pro 13" tablet


- 4** Before you can proceed, you'll need an Annotation pen. which can be loaned by ITS. Please call the ITS Help Desk at ext.4357 to schedule a pickup. The pen can be returned at the end of the semester.



- 5** Using Microsoft Word or Power Point, navigate to Review, then click on Start Inking Ink.



- 6** Choose your desired color and begin writing on the tablet's screen. The annotated text will be displayed on both the tablet and the projection screen. Click on the Eraser icon to erase any unwanted text.



- 7** Annotations on your document can be saved by clicking on File and Save. For further training contact the Help Desk at ext. 4357 to schedule a training.

View your speaker notes privately while delivering a presentation on multiple monitors

Using Presenter View is a great way to view your presentation with speaker notes on one computer (the podium computer, for example), while your audience views the notes-free presentation on the projection screen.

Set up PowerPoint to use Presenter view with two monitors

1. While on the computer desktop, click on the shortcut called **Extended Mode**. If the shortcut icon is missing, press and hold the **Windows key** and the **letter P** on your keyboard and choose **Extend**.
2. Open your desired Power Point presentation.
3. Click on the **Slide Show** tab located on the toolbar and then choose **Presenter View**.
4. You will now be able to see your notes on the computer screen while the projection screen will only display your Presentation, sans the notes.
5. Once you are finished using Presenter View please double click on the **Computer Mode** short cut on the desktop. If the shortcut is missing, press and hold the **Windows key** and the **letter P** on your keyboard and choose Duplicate.

Note: The **Windows key** on your keyboard is the key between the **Ctrl** and the **Alt** key.



Document Camera & Microphone Smart Classroom locations

Smart Classrooms with Document Cameras

New Ingersoll	Ingersoll Hall	Boylan Hall	Whitehead Hall	James Hall
238NE	1141N	3129B	208A	
431NE	2127N	3139B	222A	2412J
	2143N	3153B	305A	3203J
	2310N	3411B	320A	3613J
	3127N	3420B		5311J
	3143N	3424B		
	4141N	4145B		

Smart Classrooms with Gooseneck Microphones

Ingersoll Hall	Boylan Hall
1141N	3129B
1127N	3139B
1310N	
2143N	
2127N	
2310N	
3143N	